



BRINGING MUSIC AND MOVIES TO LIFE

HOW TO ASSOCIATE THE rWand to an rCube


- 1** Turn on master power switch on rear of rCube. The power indicator on the rCube will glow Red.
- 2** Touch the Standby button on the top panel of the rCube. The power indicator on the rCube will then glow Blue.
- 3** Touch the Wireless button on the top panel of the rCube once. It will glow steady Red.
- 4** Press and hold the Wireless button on the top panel of the rCube for 5 seconds. It will then start blinking Red.
- 5** Insert the rWand into the iDevice (iPod, iPad, iPhone) and within three seconds press and hold the button on the rWand for up to 8 seconds until the rWand Amber light blinks rapidly (about twice a second).
- 6** The iPod function of the iDevice will now automatically start.
- 7** Wait for up to 30 seconds before touching anything else. You will hear a bit of music for a moment and the Wireless button on the rCube will flash Green momentarily.
- 8** The Wireless button on the rCube will then glow steady Green and the iPod function of the iDevice will automatically start playing.
- 9** The Amber light on the rWand will flash once every 5 seconds.

Enjoy the music!

rCube Back Panel



rCube Top Panel



FOR ADDITIONAL INFO CONTACT

MIKE MARKO
marko@markoav.net
(317) 222-6226

american
audio & video



www.arcam.co.uk • www.americanaudiovideo.com

TO SEE A VIDEO ON HOW THE PROCESS WORKS VISIT

http://www.youtube.com/watch?v=NHDbt8RgCG4&feature=youtube_gdata_player